



Hjellegjerde®

Hjellegjerde AS, 6230 Sykkylven, Norway

Tel: +47 40 00 29 00 - Fax: +47 70 25 55 05

E-mail: office@hjellegjerde.com - www.hjellegjerde.com

Contents / Innhold:



Ax1



Bx1



Cx1

Hardware bag / Skruppose /



Dx4



Ex2



Fx2




Gx6



Hx1


1

1. A+C+D+H




2

2.



3

3. B+E+G



For more information, see User instruction
 For nærmere informasjon, se Brukerveiledning
 Weitere Informationen entnehmen Sie
 bitte der Gebrauchsanleitung.
 Pour plus d'information, voir les
 instructions d'utilisation.
 詳細については、取扱説明書を参照。
 Voor meer informatie, zie Gebruiksaanwijzing.
 Для получения дополнительной
 информации см. Инструкцию
 пользователя.



Scansit® R-Base




Hjellegjerde®

Hjellegjerde AS, 6230 Sykkylven, Norway

Tel: +47 40 00 29 00 - Fax: +47 70 25 55 05

E-mail: office@hjellegjerde.com - www.hjellegjerde.com

Contents / Innhold:



Hardware bag / Skrupose /

